

Quoizel, Inc.
6 Corporate Parkway
Goose Creek, SC
29445

Customer Service
Phone 631.273.2700
Fax 631.231.7102
www.quoizel.com

Assembly Instruction Sheet #IS-CKPT1484T For Style CKPT1484T

Tools Required: None

Bulb Recommended: (1) Medium Base 100W Maximum

Estimated Assembly Time: 15-20 minutes

Preparation: Identify and inspect all parts before beginning installation. Check package content list and diagrams below to be sure all parts are present. If any parts are missing or damaged, do not attempt to assemble, install, or operate the fixture. Contact customer service for replacement parts.



Warnings and Cautions


Turn off electricity at circuit breaker or main fuse box before installation. Consult a licensed electrician if in doubt.

These instructions are provided for your safety. It is very important you read them completely before installing the fixture. We strongly recommend that a licensed, professional electrician perform the installation.

Disconnect fixture from power source before replacing bulbs. Make sure bulbs are given sufficient time to cool before removal. Do not subject glass parts to any shock while in operation or shattering may result.

Package Contents

Part	Description	Quantity
A	Finial	1 pc.
B	Rubber Washer	1 pc.
C	Shade	1 pc.
D	Harp	1 pc.
E	Fixture Body	1 pc.





Thank you for purchasing a Quoizel product.

Need assistance with parts or assembly? Call Quoizel customer service at 1-631-273-2700
or visit us on-line at www.quoizel.com

CKPT1484T

FINISH: CUSTOM



(1)100W
Medium Base Bulb
(Not Supplied)

NO.	PART NUMBER	REPLACEMENT PART DESCRIPTION	REQ.
1	11484TCKPT	BASE FOR CKPT1484T	1
2	S1438WH	SHADE WHITE 11"SQ	1
3			

Assembly Instruction Sheet #IS-CKPT1484T For Style CKPT1484T

STEP 1 – Install Harp

- A. Locate the Harp (D) by pressing the ends of the Harp (D) into the Harp Clips on the top of Base (E).




Figure 1

STEP 2 – Assemble Shade

- A. Place Shade (C) and Rubber Washer (B) over the top end of the Harp (D). Secure by thread the Finial (A) onto the Harp (D). Hand tighten until snug.




Figure 2

STEP 3 – Install Bulb

- A. This fixture uses standard bulbs with medium screw bases. Maximum 100 watts.
B. Insert bulb and screw snugly into place.

Your fixture is now assembled and ready to use.
Enjoy!




Figure 3

Thank you for purchasing a Quoizel product.

Need assistance with parts or assembly? Call Quoizel customer service at 1-631-273-2700
or visit us on-line at www.quoizel.com