

WARNING! SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER .

ASSEMBLING THE FIXTURE (Fig.2)

1. Return the five arms to suitable position, see figure.2.
2. Attach the top fixture assembly (A) to the fixture body (H) by turning it clockwise until tight.
3. Attach the finial (J) to the bottom of the fixture body (H).
4. Place the socket sleeve (G) and the harp (E) over the socket of the fixture body (H), then lock it securely with the check ring (F). Install the light bulb and put the glass shade (D) on the harp (E), then screw the finial (C) onto the glass shade (D). NOTE: DO NOT EXCEED THE SPECIFIED WATTAGE!
5. Adsorb the magnet of crystal (B) to the center of the finial (C).
6. Attach the crystal (I) to top fixture body (A), fixture body (H) and the finial (J).

HANGING THE FIXTURE (Fig.1)

1. Shut off the power at the circuit breaker and remove old fixture from ceiling, including the old crossbar.
2. Carefully unpack new fixture and lay all the parts on a clear surface.
3. Thread nipple (C) into loop (F) until snug.
4. Thread other end of nipple (C) with loop attached into crossbar (D) until snug.
5. Place lock washer (B) over end of nipple protruding through crossbar and thread hex nut (A) onto nipple until tight.
6. Take this crossbar assembly and mount to ceiling junction box with junction box screws (E). Tighten screws securely with screwdriver.
7. Open one end link of the chain provided and connect to the fixture loop (K). Close the link.
8. Lace the fixture wires through the chain.
9. Slip loop collar (J) over the chain, then do the same with the canopy (G) and the iron frame (H).
10. Open the other end link of the chain and hang the fixture on the loop (F) at the ceiling. Close the link.
11. Feed the fixture wires through the loop (F) and nipple (C) and pull until taut.
12. Slide canopy (G) and the iron frame (H) up flush to ceiling, secure using loop (J).
13. Attach the crystal (I) to the small ring of the iron frame (H).

CONNECTING THE WIRES (Fig.3)

1. Take the black wire from the ceiling junction box and the smooth wire leg from the fixture and twist bare ends together. Twist wire connector onto end of wire until snug.
2. Repeat same process with white junction box wire and ribbed wire leg of fixture wire. NOTE: Twist wires together in the same direction you twist the wire connector onto wires.
3. If your junction box has a grounding wire (green or bare copper), attach this wire and the bare copper wire from the fixture together as step 1. If junction box has no ground wire, attach the bare copper fixture wire to the green ground screw on the crossbar.
4. Tuck these wire connections neatly into the ceiling outlet box and then raise the canopy (G) all the way to the ceiling. Raise the loop (H) and thread onto ceiling loop protruding through canopy

Your installation is now complete. Return power to the junction box and test the fixture.

Fig.1




Fig.2




Fig.3

