



## READ ALL INSTRUCTIONS BEFORE ASSEMBLING LAMP

**Carefully unpack lamp parts onto carpeted surface or blanket and identify all parts. Be sure to place parts in a line that closely resembles assembled lamp. All wires are connected when unpacking. Be careful handling wires during assembly.**

1. Grasp Cord that exits from Base and pull carefully until any excess Cord in between parts is removed.
2. Thread Bottom Assembly into Base and turn to tighten.
3. Thread Bottom Column into Bottom Assembly and turn to tighten.
4. Thread Middle Column into Bottom Column and turn to tighten.
5. Thread Top Column into Middle Column and turn to tighten.
6. Thread Socket Assembly into Top Column and turn to tighten.
7. Place Glass Shade onto Socket Assembly. Secure Glass Shade by fastening Counter Ring onto Threaded Socket.
8. Install Shade Ring onto top of Glass Shade.
9. Install a Type A, 150 Watt Max. 3-Way Medium Base Bulb (not included) into Socket as noted on relamping label at Socket area.

## IMPORTANT SAFETY INSTRUCTIONS:

**This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit contact a qualified electrician. Never use with a extension cord unless plug can be fully inserted. Do not attempt to defeat this safety feature.**