

Quoizel, Inc. 6 Corporate Parkway Goose Creek, SC 29445

Customer Service Phone 631.273.2700 Fax 631.231.7102 www.quoizel.com

Assembly Instruction Sheet #IS-OA1512PN For Style OA1512PN

Tools Required: Flathead screwdriver, Phillips screwdriver, pliers, wire cutters, wire strippers, electrical tape, safety glasses.

Bulb Recommended: (1) Medium Base 100W Maximum

Estimated Assembly Time: 20-30 minutes

Preparation: Identify and inspect all parts before beginning installation. Check package content list and diagrams below to be sure all parts are present. If any parts are missing or damaged, do not attempt to assemble, install, or operate the fixture. Contact customer service for replacement parts.



Warnings and Cautions


Turn off electricity at circuit breaker or main fuse box before installation. Consult a licensed electrician if in doubt.


These instructions are provided for your safety. It is very important you read them completely before installing the fixture. We strongly recommend that a licensed, professional electrician perform the installation.

Disconnect fixture from power source before replacing bulbs. Make sure bulbs are given sufficient time to cool before removal. Do not subject glass parts to any shock while in operation or shattering may result.

Package Contents

Part	Description	Quantity
Α	Crossbar	1 pc.
В	Mounting Screw	2 pcs.
С	Lock Washer	2 pcs.
D	Hex Nut	2 pcs.
E	Mounting Ball	2 pcs.
F	Lock Screw	3 pcs.
G	Ceiling Canopy	1 pc.
Н	Socket Assembly	1 pc.
I	6" Rod	2 pcs.
J	12" Rod	2 pcs.
K	Shade	1 pc.









STEP 1 - Assemble Rods

- A. Determine the Rods (I/J) to be assembled to the Socket Assembly (H) according to your hanging height.
- B. Pass Supply Wires and Ground Wire through the chosen Rods (I/J) and then thread the chosen Rods (I/J) and the Socket Assembly (H) together. Hand tighten until snug.



STEP 2 – Assemble Ceiling Canopy to Upper Rod


A. Pass Supply Wires and Ground Wire through the Ceiling Canopy (G) and then thread the Ceiling Canopy (G) and the Upper Rod together. Hand tighten until snug.






STEP 3 – Attach Mounting Screws, Lock Washers and Hex Nuts to Crossbar

- A. Line up a set of holes on the Crossbar (A) and Holes on the Ceiling Canopy (G).
- B. Thread Mounting Screws (B) into the holes on the Crossbar (A), pass Lock Washers (C) and thread Hex Nut (D) onto the Mounting Screws (B). Hand tighten until snug.



STEP 4 - Attach Crossbar to Outlet Box


A. Attach the Crossbar (A) to Outlet Box and secure by threading Outlet Box Screws (not supplied) into the Mounting Holes on the Outlet Box. Tighten until snug.





STEP 5 - Make Wire Connections

- A. Use standard wire connectors to make all wire connections. (Connectors are not included with fixture.) Strip and prepare wire ends according to instructions supplied with connectors.
- B. Connect White Supply Wire from the Outlet Box to White Wire from fixture.
- C. Connect Black (or Red) Supply Wire from the Outlet Box to Black Wire from fixture.
- D. Connect Ground Wire from the Outlet Box to Ground Wire from fixture.
- E. Twist connectors until wires are tightly joined together.
- F. Wrap each connection with approved electrical tape and carefully stuff all the connected wires into the Outlet Box.








STEP 6 – Attach Ceiling Canopy to Mounting Screw


A. Place the Ceiling Canopy (G) over the Mounting Screws (B) and secure with Mounting Balls (E). Hand tighten until snug.





STEP 7 - Install Bulb

- A. This fixture uses standard bulb with a standard screw base. Maximum 100 watts.
- B. Insert bulb and screw properly into place.



STEP 8 - Install Shade

A. Place the Shade (K) over the Bulb, attach into the Shade Holder. Thread Lock Screws (F) into the mounting holes on the Shade Holder, attach to the Neck of the Shade. Hand tighten gently until snug to secure the Shade.

Your lamp mini pendant fixture is now assembled and ready to use. Enjoy!

