

Quoizel, Inc. 6 Corporate Parkway Goose Creek, SC 29445

Customer Service Phone 631.273.2700 Fax 631.231.7102 www.quoizel.com

Assembly Instruction Sheet #IS-SPH1723PN For Style SPH1723PN

Tools Required: Flathead screwdriver, Phillips screwdriver, pliers, wire cutters, wire strippers, electrical tape, safety glasses.

Bulb Recommended: (3) Medium Base 100W Maximum

Estimated Assembly Time: 20-30 minutes

Preparation: Identify and inspect all parts before beginning installation. Check package content list and diagrams below to be sure all parts are present. If any parts are missing or damaged, do not attempt to assemble, install, or operate the fixture. Contact customer service for replacement parts.



Warnings and Cautions


Turn off electricity at circuit breaker or main fuse box before installation. Consult a licensed electrician if in doubt.

These instructions are provided for your safety. It is very important you read them completely before installing the fixture. We strongly recommend that a licensed, professional electrician perform the installation.

Disconnect fixture from power source before replacing bulbs. Make sure bulbs are given sufficient time to cool before removal. Do not subject glass parts to any shock while in operation or shattering may result.

Package Contents

Part	Description	Quantity
Α	Crossbar	1 pc.
В	Mounting Screw	2 pcs.
С	Lock Washer	2 pcs.
D	Hex Nut	2 pcs.
E	Mounting Ball	2 pcs.
F	1/8 IP Hex Nut	1 pc.
G	Socket Assembly	1 pc.
Н	Shade	1 pc.
I	Center Stem Assembly	1 pc.
J	Shade Holder	1 pc.
K	Сар	1 pc.
L	Finial	1 pc.




Thank you for purchasing a Quoizel product.


Need assistance with parts or assembly? Call Quoizel customer service at 1-631-273-2700

or visit us on-line at www.quoizel.com

September 2011

1_{of}







(3)100W Medium Base Bulbs (Not Supplied)

NOTE: ALL DIMENSIONS ARE ROUNDED UP TO THE NEAREST 1/2"


NO.	PART NUMBER	REPLACEMENT PART DESCRIPTION	REQ.
1	M280KTPN	KIT REPL PALLADIAN BRONZE	1
2	G2489SH	SHADE OPAL ETCHED GLASS 19.5"D	1

2of6




STEP 1 – Attach Mounting Screws, Lock Washers and Hex Nuts to Crossbar

- A. Unfold Side Arms on the Socket Assembly (G) to proper locations.
- B. Line up a set of holes on the Crossbar (A) and Holes on the Ceiling Canopy of the Socket Assembly (G).
- C. Thread Mounting Screws (B) into the holes on the Crossbar (A), pass Lock Washers (C) and thread Hex Nut (D) onto the Mounting Screws (B). Hand tighten until snug.



STEP 2 - Attach Crossbar to Outlet Box

A. Attach the Crossbar (A) to Outlet Box and secure by threading Outlet Box Screws (not supplied) into the Mounting Holes on the Outlet Box. Tighten until snug.



Thank you for purchasing a Quoizel product.

Need assistance with parts or assembly? Call Quoizel customer service at 1-631-273-2700


or visit us on-line at www.quoizel.com


September 2011



STEP 3 - Make Wire Connections


- A. Use standard wire connectors to make all wire connections. (Connectors are not included with fixture.) Strip and prepare wire ends according to instructions supplied with connectors.
- B. Connect White Supply Wire from the Outlet Box to White Wire from fixture.
- C. Connect Black (or Red) Supply Wire from the Outlet Box to Black Wire from fixture.
- D. Connect Ground Wire from the Outlet Box to Ground Wire from fixture.
- E. Twist connectors until wires are tightly joined together.
- F. Wrap each connection with approved electrical tape and carefully stuff all the connected wires into the Outlet Box.





STEP 4 - Attach Ceiling Canopy to Mounting Screw

A. Place the Ceiling Canopy on the Socket Assembly (G) over the Mounting Screws (B) and secure with Mounting Balls (E). Hand tighten until snug.



Thank you for purchasing a Quoizel product.

Need assistance with parts or assembly? Call Quoizel customer service at 1-631-273-2700


or visit us on-line at www.quoizel.com

September 2011




STEP 5 - Install Nipple

A. Thread the top end of the Center Stem Assembly (I) into the Hex Coupling underside of the Socket Assembly (G). Hand tighten until snug.




STEP 6 - Install Shade

A. Pass the Shade (H) and the Shade Holder (J) over the end of the Center Stem Assembly (I), attach to the Shade Stop. Secure by threading the 1/8 IP Hex Nut (F) onto the Center Stem. Hand tighten until snug.



STEP 7 - Install Cap

A. Place the Cap (K) over the end of the Nipple extruding from the bottom of the Shade (H) and secure with the Finial (L). Hand tighten until snug.



Thank you for purchasing a Quoizel product.

Need assistance with parts or assembly? Call Quoizel customer service at 1-631-273-2700

or visit us on-line at www.quoizel.com

September 2011



STEP 8 - Install Bulb

Figure 9

- A. This fixture uses standard bulbs with medium screw bases. Maximum 100 watts.
- B. Insert bulb and screw snugly into place.

Your fixture semi-flush lamp is now assembled and ready to use. Enjoy!

