

INSTALLATION INSTRUCTIONS

ITEM REFERENCE NUMBER: CHO2401AB

1. SWITCH OFF THE MAIN ELECTRICAL SUPPLY FROM THE FUSE BOX/CIRCUIT BREAKER.
2. Position mounting plate (B) diagonally so that the holes of mounting plate (B) and wall outlet (A) are aligned. Tighten mounting plate (B) onto wall outlet (A) with screws (C).
3. Connect ground outlet wire (usually green) to corresponding side (with green wire) of terminal block by loosening set screw, inserting ground wire and tightening set screw. IT IS IMPERATIVE THAT THE OUTLET BOX IN YOUR HOME BE PROPERLY GROUNDED.
4. Connect neutral (usually white) outlet wire to corresponding neutral side of terminal block by loosening set screw, inserting outlet wire and tightening set screw.
5. Repeat procedure for hot (black) wire to hot side of terminal block. Always make sure that no wire strands are left outside of the connectors. DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OTHERWISE SAFETY WILL BE COMPROMISED.
6. Gently push lantern box (F) onto outlet box (A), letting rods (D) pass through the holes on back plate of lantern box (F).
7. Position the light fixture and tighten by screwing washers/cap nuts (E) to the exposed part of rods (D) in clockwise direction.
8. Remove lantern box cap (M) by unscrewing cap nut (O) & washer (N).
9. To install glass panel (L) provided to front section, make sure the metal tab (I) is flipped up. Place glass panel to the frame, secure the glass panel by bending back the metal tab (I) downwards. Repeat this procedure for the other two sides of lantern box (F).
10. Attach light reflector (J) to hook (K). Note: Insert from the top opening of lantern box (F).
11. Replace lantern box cap (M) on top of lantern box (F) and secure with cap nut (O) & washer (N).
12. Insert light bulbs (not included) Type C, maximum 40 watt into sockets.
13. Close front door (H) and secure with key (G).

14. INSTRUCTIONS FOR MOUNTING FIXTURE OUTDOORS AND/OR IN WET LOCATION:

- a. Mounting surface should be clean, dry, flat and 1/4" larger than canopy/fixture base on all sides. Any gaps between the mounting surface and canopy exceeding 3/16" should be corrected as required.
- b. With silicone (ex. GE-108) caulking compound, caulk completely (M) around where back of canopy meets the wall surface to prevent water from seeping into outlet box.

