

AC3333 INSTALLATION INSTRUCTION

WARNING: BEFORE YOU START, NEVER ATTEMPT ANY WORK WITHOUT SHUTTING OFF THE ELECTRICITY UNTIL THE WORK IS DONE.

NOTE: THIS FIXTURE IS PARTIALLY ASSEMBLED IN THE FACTORY BY QUALIFIED CRAFTSMEN. SOME ASSEMBLY IS REQUIRED BEFORE USE. PLEASE FOLLOW ASSEMBLY INSTRUCTION CAREFULLY.

1. Hammer the plastic anchor(1) into the wall.
- 2.(1)Wire connection:connect black outlet box wire to black fixture wire with wire connector(2).

(2)Repeat the above step for white wire connection:i.e. white outlet box wire to white fixture wire.

(3)Partially thread the ground screw into the mounting bar,wrap the ground wire from fixture around the ground screw leaving enough excess wire to then connect the ground wire from outlet box with wire connector,tighten the ground screw,do not over tighten.
- 3.Use the screws(3) to fix the back plate(4) to the outlet box and use the screw(5) to fix the back plate to the plastic anchor.
4. Pass canopy(6) over the screws protruding from the back plate and secure it with the threaded ball(7).
- 5.Install lamp(8)(included),do not exceed recommended wattage and cover the bulb with the protection cover(9).
- 6.Install shades(11) as pic. shows,firstly screwing the threaded bar(10) into the rods on the canopy,and then putting the glass shades(11) onto it and secure with finial(12).

