

FLUORESCENT WALL SCONCE

ASSEMBLY & INSTALLATION INSTRUCTIONS

Please read carefully and save these instructions, as you may need them at a later date.

CAUTION

Turn off the main power at the circuit breaker before installing the fixture, in order to prevent possible shock.

GENERAL

All electrical connections must be in accordance with local and national electrical code (N.E.C) standards. If you are unfamiliar with proper electrical wiring connections obtain the services of a qualified electrician. Remove the fixture and the mounting package from the box and make sure that no parts are missing by referencing the illustrations on the installation instruction.

ASSEMBLY AND INSTALLATION

1. Turn off the power.
2. Loosen the two knobs (5) from panel (6). Take the mounting plate (3) out from the panel (6).
3. Pull the supply wires (8), (10) and house ground wire (12) out from the Junction box (1). Pull all fixture wires through the mounting plate (3).
4. Make the wiring connections: Connect the white supply wire (8) to the white fixture wire (9). Connect the black Supply wire (10) to the black fixture wire (11). Connect the house ground wire (12) and the fixture ground wire (13) using wire connector (2).
5. Carefully place all wires splices within Junction Box (1). Position the mounting plate (3) over the Junction box (1). Feed the two screws (4) through the slots on the mounting plate (3). Tighten the screw (4) into the Junction box (1) until the mounting plate (3) is flushed with the Junction box (1).

6. Position the panel (6) over the mounting plate (3). Put the panel (6) through the screws (14) and secure the panel (6) using the two knobs (5).
7. Fasten the Glass Shade (7) on the Panel (6) by knob (5) and attached Glass Guard (18) by using the Screws Head (19).
8. Remark: for one lamp version.

(1). Remove two Socket (17) from panel.

(2). Secure one of the socket (17) into the proper socket hole (16) and following step 1.2.3.4.5.6.7. for further installation.

INSTALLATION IS NOW COMPLETED

