



Contemporary
Lighting™

Installation Instructions

Model E22614-91PC

1. Turn breaker off for circuit on outlet where fixture is to be installed.
2. Install mounting bracket to electrical box.
3. Adjust cable to length. Tighten strain relief screw on canopy.
4. Wire fixture to wires in outlet box. Green wire is for Ground.
5. Install fixture to bracket and tighten 2 nuts so that fixture meets the ceiling.

Caution! This fixture is LED and cannot be installed on any dimmer. Using dimmer will damage transformer and void warranty

