



Contemporary  
Lighting™

# Installation Instructions

## Model E31206-75PC

1. Turn breaker off for circuit on outlet where fixture is to be installed.
2. Install quantity of stems on to fixture to achieve desired mounting height.
3. Install canopy to top of stems
4. Wire + wires from fixture to + (black) wires on output wires of driver transformer
5. Wire - wires from fixture to - (red) wires on output wires of driver transformer
6. Install mounting bracket to electrical box
7. Wire input wires of driver transformer on fixture to wires in outlet box.  
Connect copper ground wire to ground wire in electrical box.
8. Install fixture to bracket and tighten nuts so that fixture is secure

For maximum dimming performance we recommend Lutron CL type dimmers. Drop off or blinking may occur at the low end of dimming cycle. If this occurs adjust trim tab on CL dimmer until drop off/blinking subsides.

