



- 1) Lay frame on sturdy flat surface, with back of frame facing up.
- 2) Carefully lay mirror inside frame, with back of mirror facing up.
- 3) Set backing inside frame and on top of back of mirror.
- 4) Set clip on backing and up against frame, aligning hole in clip with hole in edge of frame.
- 5) Thread screw into hole in clip. Tighten screw to hold mirror in place.
- 6) Repeat steps #4 and #5 for remaining clips.