

- 1) Turn off power.

2) Take threaded pipe from parts bag and screw in screw collar loop a minimum of 6 mm (1/4"). Lock into place with hexnut.

3) Run another hexnut down threaded pipe almost touching first hexnut. Now screw threaded pipe into mounting strap. Mounting strap must be positioned with extruded thread faced into outlet box. Threaded pipe must protrude out the back of mounting strap. Screw third hexnut onto end of threaded pipe protruding from back of mounting strap.

4) Unscrew the threaded ring from screw collar loop. Take canopy and pass over screw collar loop. Approximately one half of the screw collar loop exterior threads should be exposed. Adjust screw collar loop by turning assembly up or down in mounting strap. Remove canopy.

5) After desired position is found, tighten top hexnut up against the bottom of the mounting strap.

6) Slip canopy over screw collar loop and thread on threaded ring. Attach chain (with fixture connected) to bottom of screw collar loop. Unscrew threaded ring, let canopy and threaded ring slip down.

7) Weave electrical wire and ground wire through chain links no more than 3 inches apart. Pass wire through threaded ring, canopy, screw collar loop, threaded pipe and into outlet box.

8) Grounding instructions: (See Illus. A or B).

A) On fixtures where mounting strap is provided with a hole and two raised dimples. Wrap ground wire from outlet box around green ground screw and thread into hole.

B) On fixtures where a cupped washer is provided. Attach ground wire from outlet box under cupped washer and green ground screw, and thread into mounting strap.
- If fixture is provided with ground wire. Connect fixture ground wire to outlet box ground wire with wire connector (not provided.) after following the above steps. Never connect ground wire to black or white power supply wires.
-
- 9) Make wire connections (connectors not provided). Reference chart below for correct connections and wire accordingly.
- | Connect Black or Red Supply Wire to: | Connect White Supply Wire to: |
|---|---|
| Black | White |
| *Parallel cord (round & smooth) | *Parallel cord (square & ridged) |
| Clear, Brown, Gold or Black without tracer | Clear, Brown, Gold or Black with tracer |
| Insulated wire (other than green) with copper conductor | Insulated wire (other than green) with silver conductor |

*Note: When parallel wires (SPT I & SPT II) are used. The neutral wire is square shaped or ridged and the other wire will be round in shape or smooth (see illus.)
- 10) Raise canopy to ceiling.

11) Secure canopy in place by tightening threaded ring onto screw collar loop.

12) Raise glass shade up to fixture, placing top of glass inside roof.

13) Pass spacer over socket and thread socket ring onto socket.

14) Insert recommended bulb.

15) Raise glass panel up to fixture. Tilt glass panel to fit inside glass shade.

16) Carefully lower glass panel and allow to rest on ledge on glass shade.
-
- 9) Haga las conexiones de los alambres (no se proveen los conectores.) La tabla de referencia de abajo indica las conexiones correctas y los alambres correspondientes.
- | Conectar el alambre de suministro negro o rojo al | Conectar el alambre de suministro blanco al |
|--|--|
| Negro | Blanco |
| *Cordon paralelo (redondo y liso) | *Cordon paralelo (cuadrado y estriado) |
| Claro, marrón, amarillo o negro sin hebra identificadora | Claro, marrón, amarillo o negro con hebra identificadora |
| Alambre aislado (diferente del verde) con conductor de cobre | Alambre aislado (diferente del verde) con conductor de plata |

*Nota: Cuando se utiliza alambre paralelo (SPT I y SPT II). El alambre neutro es de forma cuadrada o estriada y el otro alambre será de forma redonda o lisa. (Vea la ilustración).
- 10) Levante el escudete al cielo raso.

11) Sujete el escudete en el lugar apretando el anillo roscado en el ojal de collar roscado.

12) Levante la pantalla de vidrio hasta el artefacto, colocando la parte superior del vidrio adentro del techo.

13) Pase el espaciador encima del casquillo y atornille el anillo del casquillo en el casquillo.

14) Inserte la bombilla recomendada.

15) Levante el panel de vidrio hasta el artefacto. Incline el panel de vidrio para que encaje adentro de la pantalla de vidrio.

16) Cuidadosamente baje el panel de vidrio y deje que descansa en el reborde de la pantalla de vidrio.
- Si la lámpara viene con alambre a tierra. Conectar el alambre a tierra de la lámpara al alambre a tierra de la caja tomacorriente con un conector de alambres (no incluido) espués de seguir los pasos anteriores. Nunca conectar el alambra a tierra a los alambres eléctricos negro o blanco.
-
- Date Issued: 5/08/09
- IS-49049-US