



IMPORTANT:
Turn off power at main fuse or circuit breaker box before starting installation.

1. Carefully unpack and identify all parts.
2. Thread fixture wire and ground wire thru center hole of loop. Then fasten loop securely onto top fixture threaded pipe.
3. Spread open arms till they are evenly spaced to each other.
4. Screw bottom threaded pipe into coupler.
5. Sit pan on top of center glass shade and slip them thru bottom threaded pipe. Secure them with washer and hex nut until pan gently touches bottom rods.
NOTE: Glass checks into Lip on outside of pan. L-bracket of bottom rods must be located inside of pan. (See Fig 3.)
6. Slip fitter thru remaining bottom threaded pipe and secure with finial. Do not over tighten.
7. Install bulbs (not included). See relamping label located at socket area for type and maximum allowed wattage.
8. Follow enclosed "Chain Suspended Fixture Installation Instructions" for electrical and fixture installation to outlet box.

