



IMPORTANT:

Turn off power at main fuse or circuit breaker box before starting installation.

Carefully unpack and identify all parts before starting assembly.

1. Install lower arm, with leaf, onto ring by aligning holes and fastening with machine screw from behind. See left graph for correct position of lower arm. Then install bottom of arm onto bottom center body by fastening with ball cap nut. Repeat with other lower arms.
2. Lay glass shade gently onto ring.
3. Thread fixture wire from above socket assembly through center column and out of fixture loop. Screw center column onto top of socket assembly until secure.
4. Install bulbs (not included). See relamping label located at socket area for type and maximum allowed wattage.
5. Install two glass plates onto top of socket assembly by placing holes in plates through four screw studs and securing with four ball cap nuts.
6. Lay assembled fixture gently on top of glass shade. Make certain it's centered and standing straight.
7. Take upper arm and hook bottom end onto rectangular strap located at top of lower arm. See left graph for correct position of upper arm. Then install top of arm onto screw stud in center column by fastening securely with ball cap nuts. Repeat with other upper arms.
8. Follow enclosed "Chain Suspended Fixture Installation Instructions" for electrical and fixture installation to outlet box.