Assembly Instructions For

F2496/6, F2497/8



Carefully unpack and identify all parts before assembly. Bulb not included.

- I. Install suspensions arms:
 - A. First, hook bottom end of suspension arm (with fixture wires) onto loop located at main frame. Make certain to pull slack of wires from above of arm.
 - B. Then hook top end of suspension arm onto upper center body. Make certain to pull slack of wires from above of center body.
 - C. Repeat other arms (without fixture wires).
- 2. Follow enclosed supplement installation instructions for electrical and fixture installation onto house outlet box. If you do not have an outlet box at desired location to attach the fixture than hire a qualified electrician to create one.
- Install shade onto fitters by fastening with spacer tube and counter ring. Use supplied wrench to tighten counter ring.
- Install bulb (not included). See relamping label located at socket area for type and maximum allowed wattage.



