

IMPORTANT TURN OFF POWER AT MAIN FUSE TO CIRCUIT BREAKER BOX BEFORE STARTING INSTALLATION

- 1. Unpack and identify all parts.
- 2. Thread hex nut and lock washer onto threaded pipe. Twist threaded pipe onto coupler. (At least 3 turns).
- 3. Slip the following over threaded pipe: Middle Break, Bottom Half of Top font, Top half of Top Font, Rubber Washer and secure all with top final.
- 4. Follow enclosed "Fixture Installation instructions" (#2016) sheet for electrical and fixture installation onto outlet box.

M U R R A Y F E I S S