



READ ALL INSTRUCTIONS BEFORE ASSEMBLING LAMP

Carefully unpack lamp parts onto carpeted surface or blanket and identify all parts.

1. Place Iron frame onto lamp body and secure with screws.
2. Place glass shade into Iron Frame.
3. Secure glass shade into place by fastening counter ring onto socket.
4. Install a Type A, 150 Watt Max. 3-Way, Medium Base Bulb (not included) into Socket as noted on relamping label at Socket area.

IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (*one blade is wider than the other*) as a safety feature to reduce the risk of electric shock. **This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit contact a qualified electrician. Never use with a extension cord unless plug can be fully inserted. Do not attempt to defeat this safety feature.**