#### Q U O I Z E L 6 CORPORATE PARKWAY GOOSE CREEK, SC. 29445 www. quoizel. com

Quoizel, Inc. 6 Corporate Parkway Goose Creek, SC 29445

Customer Service Phone 631.273.2700 Fax 631.231.7102 www.quoizel.com

# Assembly Instruction Sheet #IS-QR1417 For Style QR1417

**Tools Required:** Flathead screwdriver, Phillips screwdriver, pliers, gloves, safety glasses.

Bulb Recommended: None.

Estimated Assembly Time: 20-30 minutes

**Preparation:** Identify and inspect all parts before beginning installation. Check package content list and diagrams below to be sure all parts are present. If any parts are missing or damaged, do not attempt to assemble, install, or operate the mirror. Contact customer service for replacement parts.




### **Warnings and Cautions**

These instructions are provided for your safety. It is very important you read them completely before installing the mirror. We strongly recommend that a licensed, professional electrician perform the installation.

## **Package Contents**

Part	Description	Quantity
Α	Mirror Hanger	2 pcs
В	Hanger Nail	4 pcs
С	Lock Screw	4 pcs
D	Bar	2 pcs
E	Mirror Frame	1 pc
F	Mirror	1 pc




Thank you for purchasing a Quoizel product.

Need assistance with parts or assembly? Call Quoizel customer service at 1-631-273-2700

or visit us on-line at <a href="https://www.quoizel.com">www.quoizel.com</a>

© 2012 Quoizel Inc. September 2012




#### Q U O I Z E L 6 CORPORATE PARKWAY GOOSE CREEK, SC. 29445 www. quoizel. com

# Assembly Instruction Sheet #IS-QR1417 For Style QR1417


#### STEP 1 - Assemble Mirror

A. Place the Mirror Frame (E) onto a flat working surface with the back facing you. Place the Mirror (F) and Bars (D) onto the Mirror Frame (E). Align the holes on Bars (D) to Mounting Holes on the Mirror Frame (E). Secure by threading Lock Screws (C) into Mounting Holes. Hand tighten until snug.



### STEP 2 - Mark Points for Mirror Hangers

- A. Lift and position where the Mirror will reside on the wall surface and with a tape measure, mark distance from floor to the bottom edge of the frame with a pencil. Mark should be located at a point representing ½ of mirror width.
- B. Place the Mirror on a flat surface with back facing you. Measure the distance from the bottom edge of the mirror frame to the bottom edge of the Crossbar. This represents distance "B" in the illustration.
- C. With tape measure, add this distance to Mark "A" on wall surface and mark with pencil.
- D. Measure distance between Turning Points on the Bars. Add less than ½ distance from Mark "B" on each side and mark with pencil. (Distance "C" in the illustration)
- E. Measure 3" up from Mark "C" and mark. These marks are locators for the (2) Mirror Hangers. Check for marks straightness with level.



Thank you for purchasing a Quoizel product.

Need assistance with parts or assembly? Call Quoizel customer service at 1-631-273-2700

or visit us on-line at www.quoizel.com

© 2012 Quoizel Inc.



# Assembly Instruction Sheet #IS-QR1417 For Style QR1417

### STEP 3 - Locate Mirror Hangers and Mirror

- A. Locate Mirror Hangers (A) and align the top center with 3" Locator mark. Secure them to wall surface with Hanger Nails (B). Please be noted that the Mirror Hangers are fully adjustable allowing for easy leveling.
- B. With Mirror Hangers properly installed, be sure that the (2) Bracket Catches are approximately equal in length from the top of Mirror Hangers (A). Adjust overall length with Adjustment Screws.
- C. With the help of another person, pass the Bar over the Mirror Hangers so that the Bar rests on the inside of the Bracket Catches.

Clean glass with household glass cleaner. Retain this sheet for future reference.

