Quoizel, Inc. 6 Corporate Parkway Goose Creek, SC 29445

Customer Service Phone 631.273.2700 Fax 631.231.7102 www.quoizel.com

Assembly Instruction Sheet #IS-TCR1508BN For Style TCR1508BN

Tools Required: Flathead screwdriver, Phillips screwdriver, pliers, wire cutters, wire strippers, electrical tape, safety glasses.

Bulb Recommended: (1) Medium Base 100W Maximum

Estimated Assembly Time: 20-30 minutes

Preparation: Identify and inspect all parts before beginning installation. Check package content list and diagrams below to be sure all parts are present. If any parts are missing or damaged, do not attempt to assemble, install, or operate the fixture. Contact customer service for replacement parts.



Warnings and Cautions


Turn off electricity at circuit breaker or main fuse box before installation. Consult a licensed electrician if in doubt.

These instructions are provided for your safety. It is very important you read them completely before installing the fixture. We strongly recommend that a licensed, professional electrician perform the installation.

Disconnect fixture from power source before replacing bulbs. Make sure bulbs are given sufficient time to cool before removal. Do not subject glass parts to any shock while in operation or shattering may result.

Package Contents

Part	Description	Quantity	
Α	Crossbar	1 pc.	
В	Mounting Screw	2 pcs.	
С	Lock Washer	2 pcs.	
D	Hex Nut	2 pcs.	
Е	Mounting Ball	2 pcs.	
F	Ceiling Canopy	1 pc.	
G	6" Rod	2 pcs.	
Н	12" Rod with Nipple	1 pc.	
I	12" Rod	1 pc.	
J	Socket Assembly	1 pc.	
K	Shade	1 pc.	
L	Socket Collar	1 pc.	




Thank you for purchasing a Quoizel product.

Need assistance with parts or assembly? Call Quoizel customer service at 1-631-273-2700 or visit us on-line at www.quoizel.com

2012 Quoizel Inc.

March2012




			1	
	NO.	PART NUMBER	REPLACEMENT PART DESCRIPTION	REQ.
	1	11508BNTCR	BASE TCR1508BN	1
	2	G3278SH	ETCHED GLASS PAINTED WHITE 6.5"D	1
_	3	9542KIT	MOUNTING HARDWARE BRUSHED NICKEL	1
	4	9006EXBN	ROD EXTENSION BRUSHED NICKEL 6"	2
	5	9012EXBN	ROD EXTENSION BRUSHED NICKEL 12"	2
-				

2of5

Assembly Instruction Sheet #IS-TCR1508BN For Style TCR1508BN


STEP 1 - Assemble Rods

- A. Determine the Rods (G/H/I) to be assembled to the Socket Assembly (J) according to your hanging height.
- B. Pass Supply Wires and Ground Wire through the chosen Rods (G/H/I) and then thread the chosen Rods (G/H/I) and the Socket Assembly (J) together. Hand tighten until snug.




STEP 2 – Assemble Ceiling Canopy to Upper Rod

A. Pass Supply Wires and Ground Wire through the Ceiling Canopy (F) and then thread the Ceiling Canopy (F) and the Upper Rod together. Hand tighten until snug.



STEP 3 – Attach Mounting Screws, Lock Washers and Hex Nuts to Crossbar

- A. Line up a set of holes on the Crossbar (A) and Holes on the Ceiling Canopy (F).
- B. Thread Mounting Screws (B) into the holes on the Crossbar (A), pass Lock Washers (C) and thread Hex Nut (D) onto the Mounting Screws (B). Hand tighten until snug.



Thank you for purchasing a Quoizel product.

Need assistance with parts or assembly? Call Quoizel customer service at 1-631-273-2700 or visit us on-line at www.quoizel.com


2012 Quoizel Inc.

March2012

Assembly Instruction Sheet #IS-TCR1508BN For Style TCR1508BN

STEP 4 - Attach Crossbar to Outlet Box

A. Attach the Crossbar (A) to Outlet Box and secure by threading Outlet Box Screws (not supplied) into the Mounting Holes on the Outlet Box. Tighten until snug.



STEP 5 - Make Wire Connections

- A. Use standard wire connectors to make all wire connections. (Connectors are not included with fixture.) Strip and prepare wire ends according to instructions supplied with connectors.
- B. Connect White Supply Wire from the Outlet Box to White Wire from fixture.
- C. Connect Black (or Red) Supply Wire from the Outlet Box to Black Wire from fixture.
- D. Connect Ground Wire from the Outlet Box to Ground Wire from fixture.
- E. Twist connectors until wires are tightly joined together.
- F. Wrap each connection with approved electrical tape and carefully stuff all the connected wires into the Outlet Box.






Figure 5

Thank you for purchasing a Quoizel product.


Need assistance with parts or assembly? Call Quoizel customer service at 1-631-273-2700 or visit us on-line at www.quoizel.com

2012 Quoizel Inc.

Assembly Instruction Sheet #IS-TCR1508BN For Style TCR1508BN


STEP 6 - Attach Ceiling Canopy to Mounting Screw

A. Place the Ceiling Canopy (F) over the Mounting Screws (B) and secure with Mounting Balls (E). Hand tighten until snug.



STEP 7 - Attach Shade to Socket


A. Place the Shade (K) over the Socket as shown. Thread the Socket Collar (L) onto the Socket to secure the Shade (K). Hand tighten until snug.



STEP 8 - Install Bulb

- A. This fixture uses standard bulb with a standard screw base. Maximum 100 watts.
- B. Insert bulb and screw properly into place.

Your lamp mini pendant fixture is now assembled and ready to use. Enjoy!



Thank you for purchasing a Quoizel product.

Need assistance with parts or assembly? Call Quoizel customer service at 1-631-273-2700

or visit us on-line at www.quoizel.com

c 2012 Quoizel Inc. Or VISIT us on-line at www.quoizei.com March2012