

ASSEMBLY INSTRUCTIONS FOR YOUR AXIS TORCHIERE

SAFETY INSTRUCTIONS:

- * This lamp comes with a polarized plug as a feature to reduce the risk of electrical shock. If the plug does not fit into your outlet, contact a licensed electrician.
- * NEVER alter the plug.
- * Remove plug from wall outlet before replacing light bulb.
- * Do not connect the electricity until lamp is fully assembled.

ASSEMBLY INSTRUCTIONS:

1. Unpack all parts and place them on a level surface.
2. Align column (C) with plate (E) and base (F). Place threaded tube (D) through hole in the center of plate (E) and base (F). Pull cord taught from below base (F) to prevent damage to the wire.
3. Hold column (C), plate (E), and base (F) together and carefully turn the lamp onto its side. Slide washer (G) onto threaded tube (D). Thread nut (H) onto tube (D) and tighten with wrench (K).
4. Carefully turn lamp into upright position.
5. Install one (1) 150W MAX Type A bulb into socket located inside shade (A).
6. Remove protective plastic (J) from polarized plug plug (I). Insert polarized plug (I) into wall outlet.
7. Use switch (B) to control power to lamp.

* To clean, use a soft cloth only. Do not use any chemical or abrasive cleaners. *

