

ASSEMBLY INSTRUCTIONS FOR YOUR

Jonathan Adler

LANCASTER ACCENT LAMP

IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug (one blade is wider than the other) as a feature to reduce risk of electric shock, this plug will fit in a polarized outlet only one way. If it does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. **DO NOT ALTER THE PLUG.**

Turn the power off (remove electrical plug from wall outlet) before replacing light bulb, making sure the bulb has had sufficient time to cool down. Do not subject the lamp to any shock while lit as shattering of bulb may result.

ASSEMBLY INSTRUCTIONS:

NOTE: Do not connect the electricity until lamp is fully assembled.

1. Unpack all parts and remove packing materials. Do not throw away any parts.
2. Place lamp base on a level surface.
3. Pass threaded insert (C) through bottom side of shade washer (B). Attach finial (A) to exposed threads on insert (C)
4. Remove flange (E) from threaded socket (G).
5. Place drop washer (F) over threaded socket (G).
6. Thread flange (E) onto socket (G) to secure shade (D) to lamp.
6. Install one (1) 60W max. Type B-10.5, candelabra base bulb into socket (G).
7. Remove protective plastic (I) from polarized plug (H).
8. Insert polarized plug (H) into wall outlet.

**** To clean, use a soft cloth only. Do not use chemical or abrasive cleaners. ****

