

## ASSEMBLY INSTRUCTIONS FOR YOUR AIDEN FLOOR LAMP

### IMPORTANT SAFETY INSTRUCTIONS:

- \* This lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If it does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do NOT alter the plug.
- \* Do not use with an extension cord unless the plug from the lamp can be fully inserted into the extension cord receptacle.
- \* Switch power off and remove plug from the wall outlet before replacing the bulb.

### ASSEMBLY INSTRUCTIONS:

NOTE: Do not connect electricity until lamp is fully assembled.

1. Unpack all parts and remove packing materials. Place lamp base on level surface.
2. Thread column (D) onto base (E). Pull cord taught from below base (E) when threading parts together to prevent damage to the wire.
3. Remove flange (A) from socket (C).
4. Place shade (B) onto socket (C). Thread flange (A) back onto socket (C).
5. Insert 1-100W Max. Type A, medium base bulb into socket (C).
6. Remove protective plastic from plug (F).
7. Insert plug (F) into wall outlet.
8. Control lamp by rotating switch on socket (C).

\*\* To clean, use a soft cloth only. Do not use any chemical or abrasive cleaners. \*\*

