
## **ASSEMBLY INSTRUCTIONS**









## **Lyon Small Semi-Flush Mount**

Item # NW 4015

WE RECOMMEND INSTALLATION OF THIS LIGHTING FIXTURE BE DONE BY A LICENSED ELECTRICIAN.

WARNING\*\*\*SWITCH OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER BEFORE INSTALLATION.

INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT. DO NOT INSTALL.

ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

NOTE: CAREFULLY UNPACK EACH PIECE IN TOP LAYER OF PACKING PRIOR TO REMOVING. RETAIN ALL PACKING MATERIAL UNTIL INSPECTION AND INSTALLATION ARE FINAL.

- 1. Carefully remove all parts from the box.
- 2. Remove the crossbar (B) from the fixture (D) by loosening the finial (E).
- 3. Affix crossbar (B) to the outlet box and secure with mounting screws (C).
- 4. Connect the hot wire (BLACK) from the fixture to the hot wire from the outlet box (usually BLACK). Fasten them together with a plastic wire connector (A) provided and wrap the connection with electrical tape.
- 5. Repeat this procedure for the neutral wire (WHITE) from the fixture to the wire from the outlet box (usually WHITE).
  - DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.
- 6. Connect ground wire from the fixture (bare copper) to ground wire from the outlet box (usually green or copper in color).
  - IT IS IMPERATIVE THAT THIS FIXTURE BE GROUNDED.
- 7. Attach the fixture onto the crossbar (B). Let threaded pipe (J) pass through the hole on the top of the fixture, and secure with finial (E).
- 8. Insert bulbs (not included) into the sockets.
- 9. Attach the crystal drops (H) one end to the hook (G1) and the other end to the hook (G2).
- 10. Hang the crystal drops (I) to the hook (G2).
- 11. Installation is complete, turn on power at fuse or circuit breaker.



<sup>\*\*\*</sup>Clean with a dry, soft cloth only. Use no harsh abrasives or chemical agents.