

Chandelier Instruction of SK5210、SK5211

We recommend installation of this lighting fixture be done by a licensed electrician. Inspect this item carefully before attempting to install. If any damage or obvious defect, do not install. Item may not be returned once it has been installed.

Pre-assembly:

1. Carefully unpack your chandelier and lay each piece on a clean, soft surface.
2. Make certain that all of the parts shown are present. Do not discard packaging material until installation is complete.
3. Make certain there are no damaged pieces. If any part is broken or missing do not attempt to install fixture.
4. This fixture has been rated for 2-75-WATT MAX. TYPE A BULBS (not included). To avoid the risk of fire, do not exceed the recommended wattage.

BE CERTAIN TO SHUT OFF THE POWER AT THE CIRCUIT BOX OR FUSE PANEL.

- 1) Provide a $\frac{1}{4}$ IPS pipe with one end securely mounted to a beam or structural member. The other end should protrude through the center of the outlet box as shown.
- 2) Connect the lower center rod (G) and upper center rod (E) by thread the lower center rod to the attached thread tube (F).
- 3) Install the crossbar (B) to outlet box (L) by using mounting screws (C) provided.
- 4) Unwrap the wiring from the top of the fixture body. Weave the power supply cord and the ground wire through the fixture.
- 5) Strip the insulation back on the two power supply wires about $\frac{5}{8}$ ".
- 6) Connect the Ground (bare) fixture wire with the ground (usually bare) wire from your ceiling box using wire nut (A). If your house does not have ground wire, then attach this wire to the green grounding screw inside of outlet box.

IT IS IMPERATIVE THAT THIS FIXTURE BE GROUNDED.

- 7) Connect the Hot (smooth edge, markings, or black) fixture wire with the Hot (usually black) wire from your outlet box using wire nut (A).
- 8) Connect the Neutral fixture wire with the Neutral (usually white) wire from your ceiling box using wire nut (A).
- 9) Tuck these wire connections neatly into the outlet box.
- 10) Raise the fixture and let the canopy(D)to outlet box, then fix them by using the side screw provided
- 11) Thread the center stem (H) to the center S-cluster,.
- 12) Assemble the shade(K) to the fixture
- 13) Install the diffuser (I) to the center stem (H) and secure with the bottom finial (J).
- 14) Insert the light bulbs (not included) (M) into sockets.
- 15) Assembly is complete.

