Assembly and Installation Instruction
Warning!!! Shut Power Off At Fuse or Circuit Breaker .

1. Carefully unpack your new fixture and lay out all the parts on clear area. Take care not to loose any small parts necessary for installation.

2.For Model No. Z14-52SF and Z14-53SF

3.Pass fixture wires through socket assembly in Canopy .

4.Attach two Mounting Screws to Mounting Strap and tighten with Hex Nuts.

5.Secure Mounting Strap to Outlet Box by threading two Outlet Box Screws through the key hole.

6.Connect the White Fixture Wire to the White Supply Wire, Connect the Black Fixture Wire to the Black Supply Wire. Make

sure all Wire Connectors are secure and do not easily pull off with the slight tug. Connect Ground Wire from the Outlet Box and Fixture Ground Wire to the Mounting Strap with the Green Grounding Screw provided.

8.After the wires connected, raise Canopy against ceiling and tighten with Finials.

9.Screw the threaded rod into the socket assembly,then place the square metal washer,shade over the threaded rod and tighten with the rubber washer and the finial securing the shade in place.

10.Insert Bulb to Socket. Return the power to the Outlet Box and test the fixture. Your installation is now complete.

WHITE SUPPLY WIRE
SUPPLY GROUND WIRE
BLACK SUPPLY WIRE
MOUNTING SCREW
MOUNTING STRAP
Hand Tool
GREEN GROUNDING SCREW
OUTLET BOX SCREW
HEX NUT
HAND TOOL
FIXTURE GROUND WIRE
BLACK FIXTURE WIRE
WHITE FIXTURE WIRE
CANOPY
FINIAL
SOCKET ASSEMBLY
THREADED ROD
METAL WASHER
SHADE
RUBBER WASHER
FINIAL

1