

Assembly and Installation Instruction

Warning!!! Shut Power Off At Fuse or Circuit Breaker .

1. Carefully unpack your new fixture and lay out all the parts on clear area. Take care not to lose any small parts necessary for installation.

2. This fixture includes three sizes of pipe:

For Model No.: Z14-54P-C Z14-55P-C

(3"X 1pc, 6"X 1PC, 12" X 3PCS)

For Model No. Z18-54P-C Z18-55P-C

(3"X 1pc, 6"X 1PC, 12"X 3PCS) to be connected into

various height. Choose desired installation height and thread fixture wires through each pipes to be used. Screw all pipes together until secure.

3. Pass fixture wires through swivel in Canopy and screw top end of pipe assembly into swivel. Connect the Pipe to the Fixture Nipple

4. Attach two Mounting Screws to Mounting Strap and tighten with Hex Nuts.

5. Secure Mounting Strap to Outlet Box by threading two Outlet Box Screws through the key hole.

6. Connect the White Fixture Wire to the White Supply Wire, Connect the Black Fixture Wire to the Black Supply Wire.

Make sure all Wire Connectors are secure and do not easily pull off with the slight tug. Connect Ground Wire from the Outlet Box and Fixture Ground Wire to the Mounting Strap with the Green Grounding Screw provided.

7. After the wires connected, raise Canopy against ceiling and tighten with Finials.

8. Place the threaded rod and finial through the Mica shade and tighten with the diffuser, washer, nut, and cap ,securing the finial in place .

9. Insert Bulb to Socket. Return the power to the Outlet Box and test the fixture. Your installation is now complete.



