







Fixture Name: **Aro 9174-3P GB**

This fixture assembled PO: \_\_\_\_\_ Date: \_\_\_\_\_

**Notice:** Please review the parts listing and check for all parts before assembling the fixture. If any parts are missing or damaged, please note on this sheet and contact the place of purchase to arrange for replacement parts.

## PARTS LIST

Company Name: \_\_\_\_\_ Co. Account #: \_\_\_\_\_  
to be filled out by retailer

Canopy 1ea Φ130mm*26mm 5.75" Dia x 1.375"E 	Mounting Screws 4ea Φ8*32mm Φ8*38mm 	Top loop 1ea Φ60mm*64mm 
Chain 1ea 6ft*3.8mm 	Wire connectors 3ea Orange 	Mounting Strap 1ea 100mm*20mm 
Chain connector 2ea 25mm*55mm 	Canopy loop and Canopy loop collar 1ea Φ30mm*50mm 	Nipple 1ea Φ12mm*55mm 
Hex Nut 2ea Φ9mm*4mm 	Green screw 1ea Φ9mm*10mm 	
Part Needed _____ Part Needed _____ Reason why (missing, scratched, broken glass, bent, bad finish) Comments _____	Quantity _____ Quantity _____	


## FIXTURE ASSEMBLY INSTRUCTIONS

**Read and review installation instruction sheet before assembling the fixture.**

- Place the Glass diffuser (O) into Fixture frame (P)
  - Place the Shade (Q) into the Fixture frame (P).
- \* There is a lip at the bottom of the Fixture frame (P) for the shade and diffuser to rest on.
- Align the bottom hole of the fixture Arm (K) with the threaded nipple on the Frame (P) edge. Secure in place with the Deco nut (M). Repeat with remaining two Arms.

**NOTE: INSTALL THE SHADE ASSEMBLY BEFORE THE FIXTURE IS HUNG.**

**NOTE: THE SHADE ASSEMBLY CAN BE DAMAGED BY ROUGH HANDLING. USE CARE WHEN ASSEMBLING.**



**For Customer Service, contact the place of purchase to arrange for replacement parts.**

# PARTS & ASSEMBLY SHEET

Fixture Name: 9174-3P GB

4. Feed the fixture wires through the Top loop (J) and pull the wires until taut.

5. Then screw the Top Loop (J) to the nipple at top of Frame (R) until tight.

8. By measuring determine correct number of links needed for proper hanging height. Use a pair of pliers to open one link of the CHAIN then remove the excess CHAIN and discard it.

9. Use one chain connector to attach one end of the chain to the Top loop (J) and close the chain connector.

10. Feed the fixture wires through the Chain (every three links) and pull the wires until taut.

11. Slip Canopy loop collar (H) over the chain, then do the same with the canopy (G).

12. When ready to complete the installation Use the other chain connector and attach the other end of the chain to the canopy loop (F) and close the chain connector.


13. Make sure the weight of the chandelier is supported by the chain-not the electrical wire.

\* You may now install the fixture.

14. Install the light bulbs in accordance with the fixture's specifications.

(DO NOT EXCEED THE MAXIMUM WATTAGE RATING)

Fig 2




For Customer Service, contact the place of purchase to arrange for replacement parts.

## WARNING ! SHUT OFF POWER AT FUSE OR CIRCUIT BREAKER.

### HANGING THE FIXTURE (Fig. 1)

- Carefully remove the new fixture from the carton and the yellow bag that holds all parts. Check that all parts are included as shown in the illustration and parts list.
- Shut off the power at the circuit breaker and remove old fixture from ceiling, including the old mounting strap.
- Thread Nipple (C) into Canopy Loop (F) until snug.
- Thread other end of the Nipple (C) with Canopy Loop attached into Mounting Strap (D).
- Place Lock Washer (B) over end of Nipple (C) protruding through Mounting Strap (D) and thread Hex Nuts (A) onto Nipple until tight.
- Take this mounting strap assembly and mount to ceiling junction box with junction box Screws (E). Tighten screw securely with screw driver.
- Unscrew the Canopy loop collar (H) from the Canopy loop. Take the canopy and pass over the Canopy loop. approximately one half of the canopy loop exterior threads should be exposed. Adjust until desired height is reached. \*the Canopy loop collar should fit snugly on the Canopy loop after the canopy is installed. Remove Canopy and Canopy lock collar.
- Assemble the fixture and have an assistant or secure support hold the weight of the fixture while you complete the wiring connections.
- Thread the fixture wires and ground wire of the assembled fixture through the canopy loop and nipple and into the outlet box.


Fig 1



### CONNECTING THE WIRES (Fig. 2)

- Attach the power supply wires to the fixture lead wires by connecting **BLACK** to **BLACK** (or **SMOOTH**) and **WHITE** to **WHITE** (or **RIBBED**).
  - Attach the **GROUND** wire (**GREEN** or **COPPER**) from the Junction Box and the fixture Ground wire to the green Ground Screw on the Mounting Bracket (D) or connect both wires together using the correct size of wire connectors.
- NOTE: Twist the wires together in the same direction you twist the wire connector onto the wires.
- Tuck these wire connections neatly into the Junction Box.

Fig. 2



### FINISHING THE INSTALLATION

- Raise Canopy (G) to the ceiling and secure in place by tightening the Canopy loop collar (H) onto the Canopy Loop (F)
- Install the light bulbs by reaching over the top of fixture shade.

**YOUR INSTALLATION IS NOW COMPLETE.  
RETURN POWER TO THE JUNCTION BOX  
AND TEST THE FIXTURE.**