

PARTS & ASSEMBLY SHEET

Fixture Name: Presilla 9363-FM GMT

his fixture	assembled PC):	Date:
I III III III C	assorrible a re		Date:

Notice: Please review the parts listing and check for all parts before assembling the fixture. If any parts are missing or damaged, please note onthis sheet and contact the place of purchase to arrange for replacement parts.

PARTS LIST	Company Name:Co. Account #: to be filled out by retailer		
Step Mounting Strap	Mounting screw		Mounting screw
1ea L104*W24*H11mm	2ea 8/32-IP*H1"		2ea 5/32-IP*H1-1/2"
Washer	Wire connnector	22000	Nipple
2ea ∮38*H2mm	3ea A3 Orange		1ea 3/8"*H145mm
Bottom cap	Finial		Hex nut
1ea § 78*H20mm	1ea ∮19*H17mm		2ea 5-32-IP*H3mm 3ea 3/8-IP*H3mm
Clip	Tube lip		Tube
2ea L40*W25*H42mm	1ea ∮27*H3mm		1ea ∮25.4*H120mm
Part Needed			Quantity
Part Needed			Quantity
Reason why (missing, scratch Comments	ned, broken glass, bent,	bad finish)	

FIXTURE ASSEMBLY INSTRUCTIONS


Read and review installation instruction sheet before assembling the fixture.

- 1. Thread the Nipple (G) into the Coupling (E), then secure with Fig 1 the Hex Nut (F-1).
- 2. Install the light bulbs in accordance with the fixture's specification .
- 3. Place the Metal ring (F) into the Glass shade (L) then hook the Clip (J) over the ring's nipple and glass edge and secure by threading the Deco nuts on till snug.
- 4. Slide the Tube (H), Tube lid (I), Washer (J) over the Nipple (G) and secure with Hex nut (K).
- 5. Place the Glass Shade (L) over the Nipple (G) slide the washer (M) over Nipple (G) and thread Hex Nut (N) on until tight.
- 7. Slide Bottom Cap (O) over Nipple (G) and secure with Finial (P).

(DO NOT EXCEED MAXIMUM WATTAGE RATING!)

NOTE: INSTALL THE GLASS ASSEMBLY AFTER THE FIXTURE IS HUNG.

9363-FM GMT



For Customer Service, contact the place of purchase to arrange for replacement parts.



INSTALLATION INSTRUCTIONS

Fixture Name: Presilla 9363-FM GMT

For Flush mount Fixture

WARNING! SHUT OFF POWER AT FUSE OR CIRCUIT BREAKER.

HANGING THE FIXTURE (Fig. 1)

- 1. Carefully remove the new fixture from the carton and the yellow bag that holes all your parts. Check that all parts are included as shown in the illustration and parts list.
- 2. Shut off power at the circuit breaker and remove the old fixture from ceiling, including the old mounting strap.
- 3. Thread the two Fixture Mounting Screws (A) into the pre-drilled Holes in the Mounting Strap (B) spaced the same distance apart as the holes in the Ceiling Pan.
- 4. Attach Mounting Strap (B) to the junction box using the two Mounting Screws (C)

CONNECTING THE WIRES (Fig. 2)

- 5. Attach the power supply wires to the fixture lead wires by connecting BLACK to BLACK (or SMOOTH) and WHITE to WHITE (or RIBBED).
- 6. Attach the GROUND wire(GREEN or COPPER) from the Junction Box and the fixture Ground wire to the green Ground Screw on the Mounting Bracket (B) or connect both wires together using the correct size of wire connectors.


NOTE: Twist the wires together in the same direction you twist the wire connector onto the wires.


7. Tuck these wire connections neatly into the Junction Box.


FINISHING THE INSTALLATION (Fig. 3)

8. Finish mounting the Ceiling Pan (D) by placing it over the Mounting Strap (B). Rotate the Pan until the Mounting screws (A) protrude through the "Keyholes" located in the bottom of Ceiling Pan (D) turn the pan until in locked position. Using a screw driver, secure the Ceiling Pan (D) by screwing Mounting Screws (A) until tightly

YOUR INSTALLATION IS NOW COMPLETE. RETURN POWER TO THE JUNCTION BOX AND TEST THE FIXTURE.







For Customer Service, contact the place of purchase to arrange for replacement parts.