

## ASSEMBLING & INSTALLATION INSTRUCTIONS PRODUCT#

FOR ITEM#: 8898-65

### WARNING

- \* Risk of shock, do not plug the unit before assembly.
- \* Do not exceed the maximum wattage rating. (Max. 150W)
- \* Before you light it up, please follow the instruction manual step by step.

### INSTALLATION

1. Slide the two bushings on the harp (D) up to expose the flat ends at the bottom.
2. Insert the flat ends of the harp (D) into the saddle (E). Then slide the two bushings down to secure the harp (D) into the saddle (E).
3. Screw in a light bulb (Type A). (Bulb is not included)
4. Place the center ring of the shade (C) over the threaded end of the harp (D). Use the finial (B) to secure the shade (C) onto the harp (D).
5. Adsorb the magnet of crystal (A) to the center of the finial (B) and attach the crystal (F) to the saddle (E).
6. Adjust the shade until it is level horizontally.

### IMPORTANT SAFETY INSTRUCTIONS

1. This portable lamp has a polarized plug (one blade is wider than the other). As a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. Do not change or alter the plug.
2. This lamp uses a 3-way switch, please use a Medium base, 3-way light bulb (50W/100W/150W).

