
INSTALLATION INSTRUCTIONS


SAFETY TIPS




Turn fixture off! (Place wall switch in off position, if fixture has built-in switch or chain pull, switch or pull chain so fixture is off.)




Next - go to the main fuse box. If your fuse box has an ON/OFF switch, Screw-in type fuses - unscrew the fuse simply place main power switch in OFF position.



or fuses that control the power to the fixture or room you are working in.





OR

CONNECT THE WIRES. NOTE: Attach black fixture wire to black supply wire, white fixture wire to white supply wire. Do not mix them up. Use approved electrical tape or wire connectors (not provided). Connect bare fixture ground wire to ground wire from outlet box. NEVER CONNECT GROUND WIRE TO BLACK OR WHITE POWER SUPPLY WIRES




FASTEN THE CAGE to post cup with the 3 screws provided




roof


FASTEN DECORATIVE TOPS to roof as shown in illustrations below which pertain to style lantern you have purchased. Thread flange nipple or nipple into finial from inside of roof as shown.




SLIP ONE HINGE PIN on roof into hole in socket on cage and snap other hinge pin into open socket



BEFORE SNAPPING HOUSING SHUT. plastic panels, textured or beveled side out, by sliding panels down cage in slots on inside of cage. Make sure panels are all the way down into seats in cage.




SCREW LIGHT BULB INTO SOCKET. Be sure to use bulb with wattage no greater than specified for this fixture. Lower roof and snap into place.



POSITION THE FIXTURE over the post as shown. For permanent mounting, fasten with set screw at hole in post collar by drilling hole at same location through post and securing with screw.


INSTALLATION INSTRUCTIONS




Turn fixture off! (Place wall switch in off position, if fixture has built-in switch or chain pull, switch or pull chain so fixture is off.)




Next - go to the main fuse box. If OFF position.



your fuse box has an ON/OFF switch, Screw-in type fuses - unscrew the fuse simply place main power switch in or fuses that control the power to the fixture or room you are working in.





FASTEN THE CAGE to post cup with the 3 screws provided




OR

CONNECT THE WIRES. NOTE: Attach black fixture wire to black supply wire, white fixture wire to white supply wire. Do not mix them up. Use approved electrical tape or wire connectors (not provided). Connect bare fixture ground wire to ground wire from outlet box. NEVER CONNECT GROUND WIRE TO BLACK OR WHITE POWER SUPPLY WIRES






FASTEN DECORATIVE TOPS to roof as shown in illustrations below which pertain SLIP ONE HINGE PIN on roof into hole to style lantern you have purchased. Thread flange nipple or nipple into finial from in socket on cage and snap other hinge pin into open socket.






inside of roof as shown.

install plastic panels, textured or beveled side out, by sliding panels down cage in slots on inside of cage. Make sure panels are all the way down into seats in cage.



SCREW LIGHT BULB INTO SOCKET. Be sure to use bulb with wattage no greater than specified for this fixture. Lower roof and snap into place.



hinge pins

roof

POSITION THE FIXTURE over the post as shown. For permanent mounting, fasten with set screw at hole in post collar by drilling hole at same location through post and securing with screw

