Quoizel, Inc. 6 Corporate Parkway Goose Creek, SC 29445

Customer Service Phone 631.273.2700 Fax 631.231.7102 www.quoizel.com

# Assembly Instruction Sheet #IS-FMCN8612C For Style FMCN8612C

**Tools Required:** Flathead screwdriver, Phillips screwdriver, pliers, wire cutters, wire strippers, electrical tape, safety glasses.

Bulb Recommended: (2) G9 Base 75W Maximum

Estimated Assembly Time: 20-30 minutes

**Preparation:** Identify and inspect all parts before beginning installation. Check package content list and diagrams below to be sure all parts are present. If any parts are missing or damaged, do not attempt to assemble, install, or operate the fixture. Contact customer service for replacement parts.



#### Warnings and Cautions


Turn off electricity at circuit breaker or main fuse box before installation. Consult a licensed electrician if in doubt.

These instructions are provided for your safety. It is very important you read them completely before installing the fixture. We strongly recommend that a licensed, professional electrician perform the installation.

Disconnect fixture from power source before replacing bulbs. Make sure bulbs are given sufficient time to cool before removal. Do not subject glass parts to any shock while in operation or shattering may result.

### **Package Contents**

Part	Description	Quantity
Α	Inner Backplate	1 pc.
В	Mounting Screw	4 pcs.
С	Fixture Body	1 pc.
D	Bulb Shield	2 pcs.
Е	Socket Collar	2 pcs.
F	Steel Collar	2 pcs.
G	G9 Bulb	2 pcs.
Н	Socket Collar Tool	1 pc.
I	Shade	2 pcs.




Thank you for purchasing a Quoizel product.

Need assistance with parts or assembly? Call Quoizel customer service at 1-631-273-2700

or visit us on-line at www.quoizel.com

December 2011



MTG HARDWARE PLSH CHRM 10"L 1 2 SHADE SQUARE CLEAR PRESSED GLS 2of5

3

4


9485KIT

G2884SH

# Assembly Instruction Sheet #IS-FMCN8612C For Style FMCN8612C


### STEP 1 – Attach Inner Backplate to Outlet Box

A. Attach the Inner Backplate (A) to Outlet Box and secure by threading Outlet Box Screws (not supplied) into the Mounting Holes on the Outlet Box. Tighten until snug.



#### STEP 2 - Make Wire Connections

- A. Use standard wire connectors to make all wire connections. (Connectors are not included with fixture.) Strip and prepare wire ends according to instructions supplied with connectors.
- B. Connect White Supply Wire from the Outlet Box to White Wire from Flip Switch Device.
- C. Connect Black (or Red) Supply Wire from the Outlet Box to Black Wire from Flip Switch Device.
- D. Connect Ground Wire from the Outlet Box to Green Ground Screw on Fixture Body (B).
- E. Twist connectors until wires are tightly joined together.
- F. Wrap each connection with approved electrical tape and carefully stuff all the connected wires into the Outlet Box.



Thank you for purchasing a Quoizel product.

Need assistance with parts or assembly? Call Quoizel customer service at 1-631-273-2700


or visit us on-line at www.quoizel.com

December 2011

# Assembly Instruction Sheet #IS-FMCN8612C For Style FMCN8612C


### STEP 3 – Attach Fixture Body to Inner Backplate

A. Place the Backplate of the Fixture Body (C) onto the Inner Backplate (A). Line up holes on both of them. Thread Mounting Screws (B) into the mounting holes on the Inner Backplate (A) and hand tighten until snug to secure them.



#### STEP 4 - Attach Shade to Socket


A. Place the Shade (I) and the Steel Collar (F) over the Socket as shown. By using the Socket Collar Tool (H), thread the Socket Collar (E) onto the Socket to secure the Shade (I). Hand tighten until snug.



#### STEP 5 - Install Bulb and Bulb Shield

- A. This fixture uses Frosted G9 Halogen Bulbs. Maximum 75 watts.
- B. Insert bulb and seat properly into place.
- C. Screw Bulb Shield (D) onto the Socket and hand tighten until snug.

Your fixture is now assembled and ready to use. Enjoy!



Thank you for purchasing a Quoizel product.

Need assistance with parts or assembly? Call Quoizel customer service at 1-631-273-2700

or visit us on-line at www.quoizel.com

December 2011

\_\_\_\_·

### Assembly Instruction Sheet #IS-FMCN8612C For Style FMCN8612C

#### SWITCHING MODE

The switching features of the product allows for you to change your lighting mode from halogen to LED.


#### STEP 6:

a. Flip the switch "ON" and the halogen lamps illuminates.

# ON...


#### **STEP 7:**

 Flip the switch "OFF" to turn off the halogen lamps for one second.




#### STEP 8:

a. Flip the switch "ON" to turn the LED lamps ON.



#### STEP 9:

a. Flip the switch "OFF" to turn off LED lamps.



#### **STEP 10:**

a. Sequence begins over.

Note: When no switch has occurred for 30 minutes, the halogen lights are programmed to come on first.

#### **CAUTION FOR BULB REPLACING**

- A. When replace bulb, turn off power and allow lamp to cool. For safety purpose, wear gloves and eye protection.
- B. If bulb is scratched or cracked, DO NOT use the lamp to avoid breakage during use or installation.
- C. Use only in fixtures rated for lamps wattage and voltage.
- D. Lamp operate under high pressure generating intense heat. Prevent contact with liquid and combustible materials.

Thank you for purchasing a Quoizel product.

Need assistance with parts or assembly? Call Quoizel customer service at 1-631-273-2700

or visit us on-line at www.quoizel.com

December 2011

5of5