

Quoizel, Inc.  
6 Corporate Parkway  
Goose Creek, SC  
29445

Customer Service  
Phone 631.273.2700  
Fax 631.231.7102  
www.quoizel.com

## Assembly Instruction Sheet #IS-LX1187TC For Style LX1187TC

**Tools Required:** None

**Bulb Recommended:** (1) Medium Base 150W Maximum

**Estimated Assembly Time:** 15-20 minutes

**Preparation:** Identify and inspect all parts before beginning installation. Check package content list and diagrams below to be sure all parts are present. If any parts are missing or damaged, do not attempt to assemble, install, or operate the fixture. Contact customer service for replacement parts.



### Warnings and Cautions


Turn off electricity at circuit breaker or main fuse box before installation. Consult a licensed electrician if in doubt.

These instructions are provided for your safety. It is very important you read them completely before installing the fixture. We strongly recommend that a licensed, professional electrician perform the installation.

Disconnect fixture from power source before replacing bulbs. Make sure bulbs are given sufficient time to cool before removal. Do not subject glass parts to any shock while in operation or shattering may result.

### Package Contents

Part	Description	Quantity
A	Shade	1 pc.
B	Finial	1 pc.
C	Harp	1 pc.
D	Base	1 pc.





Thank you for purchasing a Quoizel product.

Need assistance with parts or assembly? Call Quoizel customer service at 1-631-273-2700  
or visit us on-line at [www.quoizel.com](http://www.quoizel.com)

LX1187TC

FINISH: POLISHED CHROME



(1)150W A21  
Medium Base Bulb  
(Not Supplied)

NOTE: ALL DIMENSIONS ARE ROUNDED UP TO THE NEAREST 1/2"


NO.	PART NUMBER	REPLACEMENT PART DESCRIPTION	REQ.
1	M2282FIC	FINIAL PLSH CHRM 1.25"D X 2"H	1
2	S1340WL	SHADE WHITE LINEN HRBCK	1

## Assembly Instruction Sheet #IS-LX1187TC For Style LX1187TC

### STEP 1 – Attach Harp to Base

- A. Locate the Harp (C) by pressing the ends of the Harp (C) into the Harp Clips.

Figure 1



### STEP 2 – Attach Shade and Finial

- A. Place the Shade (A) over the nipple on the top end of the Harp (C). Secure by threading the Finial (B) onto the Harp (C). Hand tighten until snug.




Figure 2

### STEP 3 – Install Bulb

- A. This fixture uses standard bulb with standard screw base . Maximum 150 watts.  
B. Insert bulb and screw snugly into place.

Your table lamp is now assembled and ready to use.  
Enjoy!




Figure 3

**Thank you for purchasing a Quoizel product.**  
**Need assistance with parts or assembly? Call Quoizel customer service at 1-631-273-2700**  
**or visit us on-line at [www.quoizel.com](http://www.quoizel.com)**