



American by Design™

LIGHTING  
BY QUOIZEL

Quoizel, Inc.

6 Corporate Parkway  
Goose Creek, SC  
29445

Customer Service

Phone 631.273.2700

Fax 631.231.7102

www.quoizel.com

## Assembly Instruction Sheet #IS-LX6699H For Style LX6699H

**Tools Required:** None

**Bulb Recommended:** (1) Medium Base 100W Maximum

**Estimated Assembly Time:** 15-20 minutes

**Preparation:** Identify and inspect all parts before beginning installation. Check package content list and diagrams below to be sure all parts are present. If any parts are missing or damaged, do not attempt to assemble, install, or operate the fixture. Contact customer service for replacement parts.



### Warnings and Cautions


Turn off electricity at circuit breaker or main fuse box before installation. Consult a licensed electrician if in doubt.

These instructions are provided for your safety. It is very important you read them completely before installing the fixture. We strongly recommend that a licensed, professional electrician perform the installation.

Disconnect fixture from power source before replacing bulbs. Make sure bulbs are given sufficient time to cool before removal. Do not subject glass parts to any shock while in operation or shattering may result.

### Package Contents

Part	Description	Quantity
A	Harp	1 pc.
B	Base	1 pc.
C	Finial	1 pc.
D	Shade	1 pc.




Thank you for purchasing a Quoizel product.

Need assistance with parts or assembly? Call Quoizel customer service at 1-631-273-2700  
or visit us on-line at [www.quoizel.com](http://www.quoizel.com)

LX6699H

FINISH: BURNISHED BRASS



(1) 100W Medium  
Base Bulb  
(Not Supplied)

NO.	PART NUMBER	REPLACEMENT PART DESCRIPTION	REQ.
1	BN626IV	BUTN PORCELAIN IVORY	1
2	P1228FIH	FINIAL BURNISHED BRASS WITH IVORY PORCELAIN	1
3	S323WH	SHADE GLTALBST 5"X9"X9"	1



American by Design™

LIGHTING  
BY QUOIZEL

## Assembly Instruction Sheet #IS-LX6699H For Style LX6699H

### STEP 1 – Install Harp

- A. Install the Harp (A) by pressing the ends of the Harp (A) into the Harp Clips as shown.




Figure 1

### STEP 2 – Assemble Shade

- A. Place the Shade (D) over the top end of the Harp (A) and secure with the Finial (C). Hand tighten until snug.




Figure 2

### STEP 3 – Install Bulb

- A. This fixture uses standard bulb with medium screw base. Maximum 100 watts.  
B. Insert bulb and screw snugly into place.

Your fixture is now assembled and ready to use. Enjoy!




Figure 3

Thank you for purchasing a Quoizel product.  
Need assistance with parts or assembly? Call Quoizel customer service at 1-631-273-2700  
or visit us on-line at [www.quoizel.com](http://www.quoizel.com)