


INSTRUCTION SHEET IS-TFX1520T

STYLE NUMBER: TFX1520T

PACKAGE CONTENTS

ISSUED 07-2012

PART	DESCRIPTION	QUANTITY
A	Fish	1 pc
B	T7 Bulb	1 pc
C	Socket with Cord	1 pc






! CAUTIONS

- These instructions are provided for your safety. It is very important that they are read completely before the installation of your fixture. We strongly recommend that a professional electrician install the fixture.
- Disconnect fixture from the power source before replacing the bulb(s), making sure the bulb(s) had sufficient time to cool down. DO NOT subject the lamp to any shock while lit as shattering of lamp may result.

PREPARATION

- Before beginning installation of product, make sure all parts are present. Compare parts with package contents list and diagram above. If any part is missing or damaged, do not attempt to assemble, install or operate the product. Contact customer service for replacement part.
- Estimated Assembly Time : 5 - 10 minutes
- Tools Required for Assembly (included) : (1) 15W T7 Cand Base Bulb.



(1) 15W Candelabra
Base T7 Bulb
(Supplied)

NOTE: ALL DIMENSIONS ARE ROUNDED UP TO THE NEAREST 1/2"


NO.	PART NUMBER	REPLACEMENT PART DESCRIPTION	REQ.
1			

INSTALLATION INSTRUCTIONS

STYLE NUMBER: TFX1520T

STEP 1:

- a. This fixture uses T7 Bulb (Supplied) with candelabra base. Maximum 15 watts.
- b. Insert bulb and screw properly into place.



STEP 2:

- a. Place the Socket with Bulb into the Center Hole on the bottom of the Fish. The Spring Tabs on the Socket will engage the Fish.

Your fixture is now assembled and ready to use. Enjoy!

