1.



2.



3.



4.



AC773



1. This light fitting operates at a normal supply voltage of 120V
2. When changing the bulb or fuses, always switch off at the mains and allow the old bulb to cool down before handling.