




1




2



3



AC924CH



1. This light fitting operates at a normal supply voltage of 120V

2. When changing the bulb or fuses, always switch off at the main the old b and allow the old bulb to cool down before handing.