

ASSEMBLY AND INSTALLATION INSTRUCTIONS

CL1576DB/AW

WARNING: TO AVOID RISK OF ELECTRICAL SHOCK, BE SURE TO SHUT OFF POWER WHILE INSTALLING OR SERVICING THIS FIXTURE.

Installation Steps

NOTE: Do not install on ceilings with a Radiant Ceiling Heating System.

1. Carefully unpack your new fixture and lay out all the parts on a clear surface. Take care not to lose any small parts necessary for installation.
2. Attach the Circular Strap to the Outlet Box by using 2 Screws.
3. Weave the Fixture Wire and the Ground Wire through the Chain links. Spread one end of the chain link to clamp securely to the Loop.
4. Thread the Fixture Wire and ground wire through the Collar, Top loop, Canopy, Nipple-1 and Circular Strap in order.
5. Thread the Nipple-2 into the Coupling, then attach the glass, cap, and then screw with the hex nut. thread loop into Nipple-3 until tight.
6. Screw the Top Loop to the Nipple-1, and Clamp the other end of the Chain link to the Top Loop.
7. Make wire connections as follows securing with appropriate UL wire connectors.
 - The smooth wire (w/ marking) from fixture to Black Wire from power source.
 - The ribbed wire (w/o marking) from Fixture to White Wire from power source.
 - Attach the Ground Wire and house ground wire to the Circular Strap with a green Ground Screw.Carefully tuck wires back into the Outlet Box.
8. Attach the Canopy to the Circular strap by inserting the Top loop, and then screw with the Collar.
9. Screw the Nipple-2 to the coupling, place the cap, glass, hex nut in order, then screw with the loop until tight.
10. Place the cap over the Nipple-3, screw with the finial until tight.
11. Attached the Crystals onto the body according to the diagram .
12. Install the lighting bulbs in accordance with the fixture's specifications.

DO NOT EXCEED THE MAXIMUM WATTAGE RATING!

13. Turn on the power at fuse or Circuit Box.

NOTE: All parts must be used as indicated, and the physical integrity must be maintained to insure ETL/CETL listing of this fixture.

