

ASSEMBLY INSTRUCTIONS:

1. Carefully unpack parts from carton, remove covering from parts and check that all parts are included as shown in the illustration.
2. Insert the harp(C) onto the saddle(E).
3. Insert the shade (B) onto the harp (C) and secure it with finial.(A)
4. Install the bulb (D) into socket (E).

Use a 25W CFL Type bulb or 150W (Maximum) Incandescent A Type Bulb.

IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.

- ✘ PLEASE INFORM OUR DEALER IMMEDIATELY IN CASE OF ANY PARTS SHORTAGE.
- ✘ SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.

