
ASSEMBLY INSTRUCTIONS:

ITEM NO.:BO-2656TB

- 1. CAREFULLY UNPACK THE CARTON AND THEN LAY OUT ALL THE PARTS ON A SMOOTH SURFACE.
- 2. SCREW BODY DECORATION (B) INTO LAMP BODY (A), AND PULL THE WIRE OUT FROM BOTTOM OF THE BASE.
- 3. INSERT HARP (D) INTO SADDLE OF SOCKET SECTION (C).
- 4. PLACE SHADE (E) ONTO HARP (D) AND SECURE IT WITH FINIAL (F).
- 5. INSERT THE POLARIZED PLUG INTO WALL OUTLET, TURN ON THE SWITCH AND ENJOY YOUR NEW LAMP.



USE 150W (MAXIMUM) 3-WAY TYPE A BULB (BULB NOT INCLUDED)

IMPORTANT SAFETY INSTRUCTIONS:

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A SAFETY FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF IT DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS THE PLUG CAN BE FULLY AND EASILY INSERTED. DO NOT ATTEMPT TO ALTER THE PLUG.

SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.