


ASSEMBLY INSTRUCTIONS:
ITEM NO.: BO-2716-6WY-DB

1. CAREFULLY UNPACK AND PLACE ALL PARTS ON A SMOOTH SURFACE AND LINE THEM UP AS PER THE SKETCH.
2. PLACE BASE (A) ON A SMOOTH SURFACE, SCREW DECORATIVE POLE (B), TUBE (C),(D), SOCKET ASSEMBLY (E) INTO BASE(A) IN TURE, THEN PULL WIRE OUT FROM BASE.
3. INSERT HARP (F) INTO THE SADDLE OF SOCKET ASSEMBLY (E).
4. PLACE THE SHADE (G) ONTO HARP (F).
5. SCREW FINIAL (G) ONTO HARP (F) TO SECURE THE SHADE.
6. INSERT THE POLARIZED PLUG INTO WALL OUTLET, TURN ON THE SWITCH AND ENJOY YOUR NEW LAMP.

**USE TYPE A BULB 150W (MAXIMUM)
+ TYPE B BULB 40W (MAXIMUM)
3PCS (BULB NOT INCLUDED)**



IMPORTANT SAFETY INSTRUCTIONS:

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A SAFETY FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF IT DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS THE PLUG CAN BE FULLY AND EASILY INSERTED. DO NOT ATTEMPT TO ALTER THE PLUG.

SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.