

Installation Instruction

1. Squeeze harp together and insert into saddle tightly.
2. Attach the shade onto harp, then screw the finial.

Important Safety Instruction

This portable lamp has a polarized plug (One blade is wider than the other) as a safety feature to reduce the risk of the electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit in the outlet, reverse the plug. If it still does not fit, consult a qualified electrician. Never use an extension cord unless the plug can be fully inserted. Do not alter the plug.

★ **Keep this instruction for future reference**