

ASSEMBLY INSTRUCTIONS

ITEM NO: BO-2794FL

CAREFULLY UNPACK AND PLACE ALL PARTS ON A SMOOTH SURFACE.

1. SCREW POLE (A) CLOCKWISE INTO POLE (C) TO TIGHTEN.
2. SCREW POLE (C) CLOCKWISE INTO POLE (E) TO TIGHTEN.
3. SCREW POLE (E) CLOCKWISE INTO POLE (F) TO TIGHTEN.
4. SCREW POLE (F) CLOCKWISE INTO BASE (G) TO TIGHTEN. THEN GET THE REMAINING SLACK OF THE POWER CORD OUT CAREFULLY FROM BASE HOLD .
5. SCREW POLE ARM (B) AND (D) EACH CLOCKWISE TO TIGHTEN.
6. INSTALL BULB (NOT INCLUDED) INTO THE SOCKET.
7. INSERT THE POWER PLUG INTO AN OUTLET AND ENJOY!!

Use MAX 2*60 Wattage type A bulb (bulb not included)

IMPORTANT SAFETY INSTRUCTIONS:

SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF IT DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS THE PLUG CAN BE FULLY INSERTED. DO NOT ALTER THE PLUG.

