## **ASSEMBLY INSTRUCTIONS**

- FASTEN SOCKET ASSEMBLY(B) ONTO LAMP POWER CORD, TIGHTEN SECURELY. BASE(A), BE CAREFUL NOT TO TWIST THE
- 2. PLACE HARP(C) ONTO SADDLE, PLACE SHADE(D) ONTO HARP(C)
- 3. TIGHTEN FINIAL(E).

## WARNING

JUST CLEAN WITH SOFT CLOTH DO NOT USE POLISHER OR CLEANERS ON YOUR LAMP

## IMPORTANT SAFETY INSTRUCTIONS

STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG, IF IT CAN BE FULLY INSERTED FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF IT DOES BLADE IS WIDER THAN THE OTHER). AS A FEATURE TO NEVER USE WITH AN EXTENSION CORD UNLESS THE PLUG REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL THIS PORTABLE LAMP HAS A POLARIZED PLUG(ONE

