


ASSEMBLY INSTRUCTIONS:

ITEM NO.:BO-2826TB

1. CAREFULLY UNPACK THE CARTON AND THEN LAY OUT ALL THE PARTS ON A SMOOTH SURFACE.
2. SCREW SOCKET SECTION (B) INTO LAMP BODY (A), AND PULL THE WIRE OUT FROM BOTTOM OF THE BASE.
3. INSERT HARP (C) INTO SADDLE OF SOCKET SECTION (B).
4. PLACE SHADE (D) ONTO HARP (C) AND SECURE IT WITH FINIAL (E).
5. INSERT THE POLARIZED PLUG INTO WALL OUTLET, TURN ON THE SWITCH AND ENJOY YOUR NEW LAMP.



**USE 150W (MAXIMUM) 3-WAY TYPE A
BULB (BULB NOT INCLUDED)**

IMPORTANT SAFETY INSTRUCTIONS:

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A SAFETY FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF IT DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS THE PLUG CAN BE FULLY AND EASILY INSERTED. DO NOT ATTEMPT TO ALTER THE PLUG.

SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.