

FLUORESCENT FLUSH MOUNT FIXTURE ASSEMBLY & INSTALLATION INSTRUCTIONS

10860WH

Please read carefully and save these instructions, as you may need them at a later date.

CAUTION

Turn off the main power at the circuit breaker before installing the fixture, in order to prevent possible shock.

GENERAL

All electrical connections must be in accordance with local and national electrical code (N.E.C) standards. If you are unfamiliar with proper electrical wiring connections obtain the services of a qualified electrician.

Remove the fixture and the mounting package from the box and make sure that no parts are missing by referencing the illustrations on the installation instruction.


ASSEMBLY AND INSTALLATIO

1. Pull the supply wires (5&6) and the house ground wire (7) out from the outlet box (1) and attach the mounting bracket (2) to the outlet box (1) by turning the 1/2" L small head mounting screws (3).
2. Thread the 1-1/2" L big head fixture screws (4) two full turns into the appropriate threaded holes in the mounting bracket (2). Check the mounting bracket (2) against the fixture key hole slots (13) to ensure proper fit.
3. Make the wiring connections: Secure the house ground wire (7) and the fixture ground wire (10) to the ground screw (11) secured on the mounting bracket (2), as shown. Connect the white supply wire (5) to the white (or ribbed) fixture wire (8); connect the black supply wire (6) to the black (or smooth) fixture wire (9) using wire connectors (12).
4. Carefully tuck all wires back into the outlet box (1). Locate the fixture pan (14) over the outlet box (1), positioning 1-1/2" L big head fixture screws (4) heads through the large openings of the key hole slots (13). Rotate the fixture pan (14) to seat the screws, and tighten securely. (See fig.2)


5. Now you are ready to install the lamp. Do not exceed the recommended wattage shown on the caution label.

6. Carefully take the GLASS SHADE (16) and put it into the FIXTURE PAN (14). Secure the GLASS SHADE (16) with the THUMB SCREWS (15) by hand.

7. Ballasts in the fixture is accessible and removable by an electrician without cutting of wires and without damage to the housing, trim, decorative elements or the carpentry to which the fixture is attached.



Use screw driver to loosen the ballast screw and take it out of fixture pan.



Insert the Ballast to the triangle hole and then secure it by the screw on the other end.

INSTALLATION IS NOW COMPLETED

