


ASSEMBLY & INSTALLATION GUIDE

ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.



1. Attach ground (green) wire to ground wire from wall outlet box (usually green or copper in color), fasten together with a plastic wire connector. Tightly wrap the wire connector with electrical tape so the end of the connector is sealed. IT IS IMPERATIVE THAT THE OUTLET BOX IN YOUR HOME BE PROPERLY GROUNDED.
2. Connect neutral (white) fixture wire coming from fixture base to neutral (usually white) outlet wire. Fasten both wires together with a plastic wire connector and tightly wrap the wire connector with electrical tape.
3. Repeat the procedure with the hot (black) wires. Always make sure that no wire strands are left outside the connectors. DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.
4. To detach mounting plate (B) from fixture base (D) by removing cap nuts (E).
5. Position the mounting plate (B) diagonally so that the holes of mounting plate (B) and the wall outlet are aligned. Tighten the mounting plate onto the wall outlet by mounting screws (A) provided.
6. Gently push the fixture base (D) onto the wall outlet, letting rods (C) on mounting plate pass through the holes on the fixture base (D) and tighten by screwing cap nuts (E) to the exposed part of rods.
7. Insert light bulb into socket (F).
8. Clip lamp shade (G) onto the light bulb.