



READ ALL INSTRUCTIONS BEFORE ASSEMBLING LAMP

1. Carefully unpack lamp parts onto carpeted surface or blanket and identify all parts. Be sure to place parts in a line that closely resembles assembled lamp. All wires are connected when unpacking. Be careful handling wires during assembly.
2. Grasp Cord that exits at bottom of Lamp Body and pull carefully until any excess Cord in between parts is removed.
3. Thread Socket Assembly into Lamp Body and turn to tighten. Then set lamp upright on Base.
4. Place Harp fit into Yoke by squeezing bottom of Harp.
5. Install a Type A, 75 Watt Max. Medium Base Bulb (not included) into Socket as noted on relamping label at Socket area.
6. Unscrew Finial from Harp and set aside. Place Lampshade over screw thread of Harp and tighten Finial back in place.

Important safety instructions:

This portable lamp has a polarized plug (*one blade is wider than the other*) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not attempt to defeat this safety feature.