



**IMPORTANT**  
**TURN OFF THE POWER AT THE MAIN FUSE**  
**OR CIRCUIT BREAKER BOX**  
**BEFORE STARTING INSTALLATION**

**Carefully unpack and identify all parts before assembly. Bulbs are not included.**

1. Spread open arms evenly.
2. Carefully thread fixture wire through top threaded pipe. Screw top threaded pipe securely onto top coupler making certain no slack in wire remains in between. Place notched cover in between arms locking in their position.
3. Carefully thread fixture wire through fixture loop. Screw fixture loop onto top threaded pipe until secure.
4. Through bottom opening of shade, install counter ring over shade washer onto threaded socket until shades are secure. Through top opening of shade, install light bulbs (Not Included.) See relamping label at socket area for bulb type and maximum allowed wattage.
5. Follow enclosed “**Chain Suspended Fixture Installation Instructions**” for electrical and fixture installation onto ceiling outlet box.
6. This fixture is supplied with 2 threaded chain links. These links are opened and closed by twisting cylinder on chain link. One threaded chain link should be installed onto the fixture loop and the other should be installed onto the canopy loop. The standard chain should be installed in between these 2 threaded chain links.