



Fig. 1

**IMPORTANT:**  
**TURN OFF THE POWER AT THE MAIN FUSE OR CIRCUIT BREAKER BOX BEFORE STARTING INSTALLATION.**

**Carefully unpack and identify all parts before assembly. Bulbs are not included.**

1. Spread open arms so they are evenly spaced to each other.
2. Slide up the lower notched cap until arms are locked into it's notches. Then lock into position by tightening with decorative nut.
3. Thread fixture wires through upper notched cap and fixture loop. Then slide down the notched cap until the arms are locked into it's notches. Screw fixture loop onto protruding threaded pipe until secure.
4. Install small finial onto bottom section of fitters.
5. Install the side glass shade onto fitters by fastening with counter ring.
6. Install light bulbs (not included). See label located at socket area for type and maximum allowed wattage.
7. Follow enclosed **"Chain Suspended Fixture Installation Instructions"** for electrical and fixture installation onto ceiling outlet box.
8. Assemble center glass shade:
  - A. Install a hex nut onto one end of long threaded pipe leaving about 1/2" (13 mm) thread exposed. Screw same end of threaded pipe into coupler. Tighten hex nut.
  - B. Sit pan on top of the center glass shade. Note correct position of pan on fig. 1 which shows detailed cross section view.
  - C. Then carefully slide center glass shade through the threaded pipe until pan is pressed against bottom section of arms. Note : Pins located at bottom section of arms must locate into corresponding holes in pan. Secure glass shade by sliding a cap (note correct position - open side of cap facing glass) and fastening with hex nut.
  - D. Slip font through same threaded pipe and secure in position by fastening with a large finial.