



READ ALL INSTRUCTIONS BEFORE ASSEMBLING LAMP

Unpack lamp parts onto carpeted surface or blanket. Be sure to place parts in a line that closely resembles assembled lamp. All wires are connected when unpacking. Be careful handling wires during assembly.

1. Grasp Cord that exits at the bottom of lamp base and pull carefully until excess Cord in between parts is removed.
2. Thread Center Column into Lamp Base and turn to tighten.
3. Thread Lamp Body into Center Column and turn to tighten.
4. ☐ Place Harp base into Yoke by squeezing the bottom of Harp.
5. Install a Type A, 150 Watt Max. 3-Way Medium Base bulb (bulb not included) in socket as noted on relamping label at Socket area.
6. Unscrew Finial from Harp and set aside. Place Lamp Shade over screw thread of Harp and tighten Finial back in place.

IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with a extension cord unless plug can be fully inserted. Do not attempt to defeat this safety feature.